


How to attach Fixed Shelf and Pull Out Hanger into your Cabinet



*Please Note:
Cabinet number shown is an example only.*

Pull Out Hanger Hardware and Fixed Shelf

Fixed Shelf



Pull Out Hanger



15mm Wood Screw



This shelf is attached by inserting Cam Pins into the Shelf Pin Holes at your desired height. There are no pre-drilled holes for attaching the Pull-out Hanger to the shelf.

Attaching the Pull Out Hanger

- Measures the WIDTH of the shelf, mark the centre of the shelf at both the front edge & the back edge of the Fixed Shelf.
- Place the pull-out hanger, so these marks are in the centre of the Black attachment mould, ensure the front of the pull-out hanger is set back from the front edge (edge tape).
- Fix the Pull-Out hanger to the shelf using the 4 x 15mm wood screws.

Caution: Do Not over tighten the wood screws into the shelf as it may end up protruding through the shelf panel

Attaching the Fixed Shelf - Once the preferred height for the pull-out hanger has been chosen, insert the Cam Pins into the Shelf Pin Holes.

Insert the shelf so the cam locks and cam pins are interlocked and then tighten the cam locks.